

Instruction Manual

12-inch TFT LCD monitor

PYRAMID
WWW.PYRAMIDCARAUDIO.COM

MV1240IR



HAZARD WARNING:
PLEASE DO NOT OPERATE THIS
UNIT UNLESS VEHICLE IS PARKED
IN SAFE AND LEGAL AREA

Control panel



1. Power on/off
2. Menu
3. AV1/AV2
4. Adjust -
5. Adjust +
6. IR transmitter
7. Light

Performance parameter

Type: TFT LCD

Display size: 12"

IR transmitter

Two video inputs


Resolution: 800X600

System: NTSC/PAL

Remote control


Power supply: DC 12V

Remote control




-  Power switch
-  V1/V2
-  Decrease
-  Increase
-  Menu
-  Mode select

Method of wiring



Insert to LCD terminal

Yellow to video 1
Yellow to video 2



Red to battery +12V
Black to grounding
Yellow to door control